




SEIKO

DIGITAL QUARTZ


Cal. F039A

PARTS LIST

Cal. F039A




4001 321




4245 321




4293 320



4313 320



4398 321




4398 323



4408 320



4510 261



4521 019




4530 010



4540 006



☆Maxell SR1130W



Cal. F039A

Characteristics

Casing diameter: ϕ 25.6mm
 Maximum height: 4.4 mm without battery
 Frequency of quartz crystal oscillator: 32,768 Hz (Hz=Hertz Cycles per second)
 Time display: 12-hour Digital Display System showing hour, minute and second.
 Calendar display: The day and date are displayed by depressing the side button.
 Display medium: Single Crystal Display (Nematic Liquid Crystal, FE-Mode)
 Regulation system: Trimmer condenser
 Illuminating light: Illuminates the display in the dark

PART NO.	PART NAME	PART NO.	PART NAME
4001 321	Circuit block		
4245 321	Switch spring		
4293 320	Switch cock		
4313 320	Connector		
4398 321	Battery guard		
4498 323	Liquid crystal panel frame		
4408 320	Insulating spacer for circuit block		
4510 261	Liquid crystal panel		
4521 019	Reflecting mirror		
4530 010	Bulb		
4540 006	Spring for liquid crystal panel		
012 470	Screw for battery guard		
017 193	Tube for battery guard screw		
☆Maxell SR1130W ☆Toshiba WG10 ☆U.C.C. 389	Silver oxide battery		

Remarks :

Battery

☆Maxell SR1130W }
 ☆Toshiba WG10 } The applied battery for this calibre might be added the substitutive in the future.
 ☆U.C.C. 389 } In that case, please refer to separate "BATTERIES FOR SEIKO QUARTZ WATCHES".

☆☐ Please see remarks.
 Part numbers in light letters are not shown in photos.